



# SWITCH CONTINUITY

TURN SIGNAL SWITCH	W	R	L	BATS	PR	PL
R	○					
N						
L			○			
COLOR	Gr	Lb	O	Br/W	Lb/W	O/W

DIMMER SWITCH	HL	Lo	Hi
Lo	○		
Hi		○	
COLOR	Bu/W	W	Bu

HORN SWITCH	HO	BAT3
FREE	○	
PUSH		○
COLOR	Lb	Br/Br

- FUSE BOX
- A 20A (HEADLIGHT)
  - B 10A (NEUTRAL • OIL • TACHO • SPEED • TEMP • POSITION • METER LIGHT • TAIL)
  - C 10A (TURN SIGNAL • FRONT, REAR BRAKE • HORN)
  - D 10A (STARTER • ENGINE STOP SENSOR)
  - E 10A (FAN MOTOR)
  - F 10A (CLOCK)

IGNITION SWITCH	FAN	IG	BAT1
ON	○		
OFF		○	
LOCK			○

ENGINE STOP SWITCH	IG	BAT2
OFF	○	
RUN		○
COLOR	Bi	W/Br

STARTER SWITCH	ST	IG	BAT3	HL
FREE	○			
PUSH		○		
COLOR	Y/R	Bi	Br/Br	Bu/W

- BI ..... BLACK    Br ..... BROWN  
Y ..... YELLOW    O ..... ORANGE  
Bu ..... BLUE    Lb ..... LIGHT BLUE  
G ..... GREEN    Lg ..... LIGHT GREEN  
R ..... RED    P ..... PINK  
W ..... WHITE    Gr ..... GRAY